


### VSA Series

### VSA-EDxxx Series (+EDID Function)

### VSVA Series (+Audio)



Rexton Video Switch is a simple and stable solution, allowing users quickly and easily sharing a varied type of interfaces (VGA / DVI / HDMI and DisplayPort), display devices (HDTV, Blu-ray player, HD-DVD, Xbox, Wii, PS3, Satellite receiver...etc.) from your device inputs to one output device (monitor, projector, or TV). You can select the desired input source via the remote control within the range of 5 meters or push button located on the switch. It totally removes the need to plug & unplug Video sources, making the user's A/V equipments more convenient, more affordable and more efficient. Furthermore, the built-in serial interface allows users controlling the Video Switch through a PC, serial controller devices or home theater system integrating the whole A/V environment.



## Features

- Select 1 Video (+ Audio) from 2 / 4 / 8 different Video (+ Audio) sources
- Front panel buttons for easy switching
- LED shows active status and makes operation user-friendly
- Support video resolution up to UXGA (1600 x 1200) / Full HD (1920 x 1080) / WUXGA (1920 x 1200)
- Compatible with most of the popular screen resolution to XGA, SXGA, UXGA, WSXGA ....Full HD, WUXGA system

### System Control

- Support IR remote control
- Support serial remote control

### EDID Functions

- EDID functions effect simultaneously of all video sources
- EDID Copy function makes the best video presentation
- Read and store the EDID from the connecting display to the video extension system
- Provide a default EDID, if a display's EDID is not available
- Alternatively perform the default or the copied EDID for the connected display device
- Emulating EDID information ensures the optimum video performance

### EGO Functions (VSA-EDxxx)

- User-friendly port switching via button pressing or priority setting
- In priority setting, users can set port-n as the priority video source

## Comparison Table

	Model	Input	Output	Audio	IR Control	Serial Control	Hotkey Control	EDID Function	Ego Function
(Basic)	VSA-401	4	2	N/A	N/A	N/A	Yes	N/A	N/A
	VSA-801	8	2	N/A	N/A	N/A	Yes	N/A	N/A
(Basic)	VSVA-401	4	1	Yes	Yes	N/A	N/A	N/A	N/A
	VSVA-S401	4	1	Yes	Yes	Yes	N/A	N/A	N/A
(Advanced)	VSA-ED201	2	1	N/A	N/A	N/A	N/A	Copy only	Yes
	VSA-ED221	2	1	N/A	N/A	N/A	N/A	Copy+Emulate	Yes
(Advanced)	VSA-ED401	4	1	N/A	Yes	Yes	N/A	Copy only	Yes
	VSVA-ED401	4	1	Yes	Yes	Yes	N/A	Copy only	Yes
	VSA-ED801	8	1	N/A	Yes	Yes	N/A	Copy only	Yes
	VSVA-ED801	8	1	Yes	Yes	Yes	N/A	Copy only	Yes